

Service Manual

ORDER NO.
CRT4073

CLASS D MONO AMPLIFIER

PRS-D2000SPL/XS/UC
PRS-D2000SPL/XSEW5

This service manual should be used together with the following manual(s) listed below. For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
PRS-D2000SPL/XU/UC	CRT3934		

SAFTY INFORMATION

WARNING

A This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.
Health & Safety Code Section 25249.6 - Proposition 65

EXPLODED VIEWS AND PARTS LIST

PACKING(Page 22)

PACKING SECTION PARTS LIST

B

Mark	No.	Description	PRS-D2000SPL/XU/UC	PRS-D2000SPL/XS/UC
	12	Unit Box	CHG6196	CHG6332
	13	Contain Box	CHL6196	CHL6332

Mark	No.	Description	PRS-D2000SPL/XUEW5	PRS-D2000SPL/XSEW5
	12	Unit Box	CHG6197	CHG6333
	13	Contain Box	CHL6197	CHL6333


C

D

E

F

Service Manual



ORDER NO.
CRT3934

CLASS D MONO AMPLIFIER

PRS-D2000SPL_{XU/UC}
PRS-D2000SPL_{XUEW5}



For details, refer to "Important check points for good servicing".

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2007

SAFETY INFORMATION

A CAUTION

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

B WARNING

This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65

C

D

E

F

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.
Please be sure to confirm and follow these procedures.

1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.

Use genuine parts. Be sure to use important parts for safety.

- ② Do not perform modifications without proper instructions.

Please follow the specified safety methods when modification(addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.

- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris.
Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.

Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.

Please be sure that all connectors are inserted, and that there are no imperfect insertion.

- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs.
In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.

Please check that neither solder debris nor screws remain inside the product.

- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages.
If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.

When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.

- ⑩ Safe environment should be secured during servicing.

When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries.
Please pay attention to your surroundings and repair safely.

2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification.
Adjustments should be performed in accordance with the procedures/instructions described in this manual.

3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance.
Make sure the proper amount is applied.

4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

A

B

C

D

E

F

CONTENTS

SAFETY INFORMATION.....	2
1. SERVICE PRECAUTIONS	5
1.1 SERVICE PRECAUTIONS	5
1.2 NOTES ON SOLDERING	5
2. SPECIFICATIONS	6
2.1 SPECIFICATIONS	6
2.2 PANEL FACILITIES.....	7
2.3 CONNECTION DIAGRAM	8
3. BASIC ITEMS FOR SERVICE.....	9
3.1 CHECK POINTS AFTER SERVICING.....	9
3.2 JIGS LIST	10
4. BLOCK DIAGRAM.....	11
5. DIAGNOSIS.....	12
5.1 CONNECTOR FUNCTION DESCRIPTION.....	12
B 6. SERVICE MODE	13
7. DISASSEMBLY	14
8. EACH SETTING AND ADJUSTMENT	20
8.1 ADJUSTMENT	20
9. EXPLODED VIEWS AND PARTS LIST.....	22
9.1 PACKING	22
9.2 EXTERIOR(1)	24
9.3 EXTERIOR(2)	26
10. SCHEMATIC DIAGRAM.....	30
10.1 AMP UNIT(GUIDE PAGE)	30
10.2 POWER SUPPLY UNIT(GUIDE PAGE).....	36
10.3 REMOTE CONTROL UNIT.....	42
C 11. PCB CONNECTION DIAGRAM.....	44
11.1 AMP UNIT	44
11.2 POWER SUPPLY UNIT	48
11.3 REMOTE CONTROL UNIT	52
12. ELECTRICAL PARTS LIST	53

1. SERVICE PRECAUTIONS

1.1 SERVICE PRECAUTIONS

● Service Precaution



1. You should conform to the regulations governing the product (safety, radio and noise, and other regulations), and should keep the safety during servicing by following the safety instructions described in this manual.
2. Be careful in handling ICs. Some ICs such as MOS type are so fragile that they can be damaged by electrostatic induction.
3. The area where the temperature gets high as a completely assembled product is the heat sink. As a unit, on the other hand, sub-heat sink and the periphery of the sub-heat sink are the areas where the temperature gets high.
4. There is a danger for electrical shock in the periphery of an area where "CAUTION High Voltage" is indicated on the printed circuit board due to a high voltage being generated during operation. Therefore, be careful when working around such areas.
5. The Holder Unit(CXC8183) cannot be used again when removing once. Please exchange it for new parts when you remove the Holder Unit from the product. Reattachment of the Holder Unit having once peeled off may possibly leak the light from an aperture generated by the weak adhesion of two-sided tape.
6. Since the secondary voltage is not discharged upon power-off of the product after the product operation check (some residual voltage is left even after five minutes), forcibly discharge the voltage or conduct servicing after checking the voltage with a tester.
7. When replacing the power FET or the output FET, parts connected in parallel need to be replaced at the same time.

A

B

C

D

1.2 NOTES ON SOLDERING

NOTES ON SOLDERING

- For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit. Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.
- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C. Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

- Parts numbers of lead-free solder:
 - GYP1006 1.0 in dia.
 - GYP1007 0.6 in dia.
 - GYP1008 0.3 in dia.

E

F

2. SPECIFICATIONS

2.1 SPECIFICATIONS

A	Power source	14.4 V DC (10.8 V to 15.1 V allowable)
	Grounding system	Negative type
	Backup current	3 mA or less
	Current consumption	67 A (at continuous power, 4 Ω)
	Average current drawn*	18 A (4 Ω for one channel) 38 A (2 Ω for one channel) 55 A (1 Ω for one channel)
	Fuse	40 A × 6
	Dimensions	586 (W) × 65 (H) × 282 (D) mm [1 ft. 11 in. (W) × 2-1/2 in. (H) × 1-1/8 in. (D)]
	Weight	9.1 kg (20 lbs.) (Leads for wiring not included)
	Maximum power output	1 500 W × 1 (4 Ω) / 3 000 W × 1 (2 Ω) / 4 000 W × 1 (1 Ω)
	Continuous power (14.4 V)	4 Ω, 20 Hz to 240 Hz, ≤ 1.0 % THD, 750 W × 1 2 Ω, 50 Hz, ≤ 1.0 % THD, 1 500 W × 1 1 Ω, 50 Hz, ≤ 1.0 % THD, 2 000 W × 1
B	Load impedance	4 Ω (1 Ω to 8 Ω allowable)
	Frequency response	10 Hz to 240 Hz (+0 dB, -3 dB)
	S/N ratio (UC model)	85 dB (IHF-A network)
	(EW5 model)	85 dB (IEC-A network)
	Distortion	0.3 % (10 W/4 Ω, 100 Hz)
	Low pass filter	Cut off frequency: 40 Hz to 240 Hz Cut off slope: -24 dB/oct.
	Subsonic filter (HPF)	Frequency: 20 Hz Slope: -24 dB/oct.
	Bass boost	Frequency: 40 Hz to 120 Hz Level: 0 / 6 / 9 / 12 dB
C	Gain control	RCA: 400 mV to 6.5 V
	Maximum input level / impedance	RCA: 6.5 V / 22 kΩ
	(UC model)	
	Power output	750 W RMS × 1 channel (at 4 Ω and ≤ 1% THD+N) 1 500 W RMS × 1 channel (at 50 Hz, 2 Ω and ≤ 1% THD+N) 2 000 W RMS × 1 channel (at 50 Hz, 1 Ω and ≤ 1% THD+N)
	S/N ratio	60 dBA (reference: 1 W into 4 Ω)



Note:

- Specifications and the design are subject to possible modification without notice due to improvements.

*Average current draw

- The average current drawn is nearly the maximum current drawn by this unit when an audio signal is input. Use this value when working out total current drawn by multiple power amplifiers.

2.2 PANEL FACILITIES

Terminal Cover

MODE SELECT switch
 You can select amplifier's sync mode from MASTER, SYNC and SYNC INV. Set the MODE SELECT switch to the MASTER position when using one amplifier only. When using synchronously connecting two or more of these amplifiers in combination, set the first amplifier to MASTER, and set the remaining amplifiers to SYNC or SYNC INV according to the manner in which they are connected. The only time the amplifier is switched to the SYNC INV mode is when amplifiers are synchronously connected with the ex. bridge.
 When switching to the SYNC or SYNC INV mode, remove the screw and stopper. Remove the screw and stopper after checking that connections are correct.

Gain Control
 Before setting up the unit, unscrew the terminal cover with a 4 mm hexagonal wrench and remove the terminal cover.

- If the sound level is too low, even when the volume of the car stereo used along with this power amplifier is turned up, turn gain control clockwise. If the sound distorts when the volume is turned up, turn the gain control counter-clockwise.
- When using with an RCA equipped car stereo (standard output of 500 mV), set to the NORMAL position. When using with an RCA equipped Pioneer car stereo with max. output of 4 V or more, adjust level to match the car stereo output level.

Bass Boost Frequency Control

You can select a bass boost frequency from 40 Hz to 120 Hz with the bass boost control.

HEAT Indicator (Yellow)

This indicates a problem with the amplifier.

BFC (Beat Frequency Control) Switch

If you hear a beat while listening to an AM broadcast with your car stereo, change the BFC switch using a small standard tip screwdriver.

PROTECT Indicator (Red)

This indicates a problem with the amplifier.

Power Indicator (Blue)

The power indicator lights when the power is switched on.

Subsonic Select Switch

The subsonic filter cuts inaudible frequencies below 20 Hz to eliminate unwanted vibrations and minimize power loss.

Cut Off Frequency Control for LPF

You can select a cut off frequency from 40 Hz to 240 Hz.

Bass Boost Level Control

You can select a bass boost level from 0, 6, 9 and 12 dB.

2.3 CONNECTION DIAGRAM

A

B


C

D

E

F

- In the case of connecting the external output from a car stereo to an RCA input, use the jack used for full-range output. This is because the LPF of the amplifier cannot be turned OFF. If this jack cannot be used, connect the subwoofer output jack to the RCA input.



3. BASIC ITEMS FOR SERVICE

3.1 CHECK POINTS AFTER SERVICING

A

To keep the product quality after servicing, please confirm following check points.

No.	Procedures	Item to be confirmed
1	Confirm whether the customer complain has been solved.	The customer complain must not be reappeared. Audio and operations must be normal.
2	Check the output sound.	Audio and operations must be normal.
3	Appearance check	No scratches or dirt on its appearance after receiving it for service.

See the table below for the items to be checked regarding video and audio:

Item to be checked regarding audio
Distortion
Noise
Volume too low
Volume too high
Volume fluctuating
Sound interrupted

B

C

D

E

F

3.2 JIGS LIST

● Lubricants and Glues list

Name	Jig No.	Remarks
Bond	GEM1017	Applying to Chemical Capacitor etc. (*)
Bond	GYL1006	Applying to Thermistor

(*) You can use GEM1017 even if the color is different from the original ones.

B

C

D

E

F

4. BLOCK DIAGRAM

There is no information to be shown in this chapter.

A

B

C

D


E

F

5. DIAGNOSIS

5.1 CONNECTOR FUNCTION DESCRIPTION

A




B

C

D

E

F



6. SERVICE MODE

There is no information to be shown in this chapter.

A

B

C

D

E

F

7. DISASSEMBLY

A You can see the Screws List on the page 28.

● Removing the Case (Fig.1)


- 1 Remove the eight screws.
- 2 Remove the nine screws and then remove the Case.



Fig.1

E Note)

When removing the case, remove it from the positioning side. Removal from the opposite side may deform the positioning pin. (Fig.2)



Positioning pin

Fig.2

Note)

This product has high voltage circuits inside, and the voltage will be kept for a while by big capacitors. So, before starting disassembly (especially removing the Buss Bars (CND3947)), make sure if the voltage of +VH and -VH become low enough after turning off the power supply (+B & ACC). If you want to discharge the capacitors faster, connect the resistors of same value in parallel with the original discharge resistors (R241 - R246).

● Removing the Amp Unit (Fig.3)

- 1** Remove the eight screws and then remove the four Buss Bars.
- 2** Remove the two screws.
- 3** Remove the four screws.
- 4** Remove the seven screws.
- 5** Disconnect the Connector and then remove the Amp Unit.

Note)

Removal of substrate while the Buss Bar being connected will deform the Buss Bar, failing to set up again.




Fig.3

Note)

Remove a screw for MODE SELECT only when switching over the mode selection. You do not have to remove this screw when removing the unit board. (Fig.4)




Fig.4

● Removing the Power Supply Unit (Fig.5)

- A  1 Remove the two screws.
-  2 Remove the two screws.
-  3 Remove the four screws.
-  4 Remove the eight screws and then remove the Power Supply Unit.







Fig.5




- Bonding Position
- Amp Unit



● Power Supply Unit

A




B


C

D

E

F







(A) : Should be mounted closely.

(A) : The styling of lead of TH, must be straight.
(pay attention to a photograph.)


③ 2 pts : GYL1006



③ Apply bond to FET



When installing a Spring for holding of Thermistor, tighten a screw while pushing down the spring.



Place a Thermistor at the center of FET such that the rightmost terminal of FET and the Thermistor terminal are separated by 1 mm or more.


8. EACH SETTING AND ADJUSTMENT

8.1 ADJUSTMENT



● Connection Diagram

AMP UNIT (SIDE A)



● Speaker Output DC Offset Voltage Adjustment

No.	Measurement condition	Measurement point	Adjustment point	Adjustment Method
1	Power on 4 Ω, no input $R_g = 1\text{ k}\Omega$	SP OUT	VR801	DC voltmeter : $0 \pm 15\text{ mV}$

■ 5

■ 6

■ 7

■ 8

■ A

■ B

■ C

■ D


■ E

■ F

9. EXPLODED VIEWS AND PARTS LIST

NOTES : • Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.
• The mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
• Screw adjacent to mark on the product are used for disassembly.
• For the applying amount of lubricants or glue, follow the instructions in this manual.
(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING



PACKING SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Screw Assy	CEA7771	13	Contain Box(UC)	CHL6196
2	Screw	BYC30P100FTB		Contain Box(EW5)	CHL6197
3	Screw	BYC40P180FTB			
4		14	Protector	CHP3367
5	Shaft	CLP1246	15	Protector	CHP3368
			16-1	Owner's Manual(UC)	CRD4225
6	Shaft	YLP5001		Owner's Manual(EW5)	CRD4224
7	Shaft	CLP1252	*	16-2 Warranty Card(UC)	CRY1070
*	8 Polyethylene Sheet	CNM4338	*	Warranty Card(EW5)	CRY1157
*	9 Polyethylene Bag	CEG-158	17	Cord Assy	YDP5002
10	Polyethylene Bag	CEG1116	18	Remote Control Assy	CXC4064
11	Cover	CEG1381	*	19 Polyethylene Bag	CEG1171
12	Unit Box(UC)	CHG6196	*	20 Lock Tie	CNV-754
	Unit Box(EW5)	CHG6197			

Owner's Manual, Installation Manual

Part No.	Language
CRD4225	English, French, Spanish
CRD4224	English, Spanish, German, French, Italian, Dutch, Russian

A

B

C


D

E


F

1 2 3 4
9.2 EXTERIOR(1)


A




B




C



D



E



F



EXTERIOR(1) SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Screw	BBZ30P060FTC	30	Holder(CN754)	CND3898
2	Screw	BSZ30P060FTC			
3	Screw(M2.6 x 6)	CBA2115	31	Holder	CND3943
4	Screw(M3 x 5)	CBA1810	32	Holder	CND4097
5	Screw(3 x 12)	CBA2012	33	Sub Heat Sink	CNR1901
			34	Sub Heat Sink	CNR1902
6	Screw(M3 x 10)	CBA2064	35	Screw	PPZ30P100FTB
7	Cord Assy	CDE8431			
8	Case	CNB3376	36	Terminal(CN581)	VNF1084
9	Buss Bar	CND3947	37	Terminal(CN681)	VNF1084
10	Heat Sink	CNR1899	38	Terminal(CN705)	VNF1084
			39	Terminal(CN881)	VNF1084
11	Cover	CNR1915	40	Terminal(CN882)	VNF1084
12	Spacer	CNV8256			
13	Clamper	CNV9663	41	Remote Control Assy	CXC4064
14	Amp Unit	CWH1347	42	Screw	BPZ20P100FTB
15	Screw	AMZ30P040FTC	43	Grille	CNS8140
			44	Cover	CNS8141
16	Screw	BBZ30P060FSN	45	Remote Control Unit	CWM9848
17	Screw	BSZ30P060FTB			
18	Screw(3 x 8)	CBA2011	46	Connector(CN1351)	CKS4962
19	Pin Jack(CN601)	CKB1083	47	Knob Unit	CXC4335
20	Pin Jack(CN501)	CKB1069	48	Spring	CBL1692
			49	Lighting Conductor Unit	CXC8164
21	Terminal(CN891)	CKE1061	50	Lighting Conductor Unit	CXC8165
22	Screw(M8 x 10)	CBA2059			
23	Plug(CN502)	CKS1041	51	Badge Unit(UC)	CXC8173
24	Connector(CN561)	CKS4962		Badge Unit(EW5)	CXC8174
25	Panel	CNB3374	52	Holder Unit	CXC8183
			53	Screw	PMH40P060FTC
26	Holder	CND2466	54	Screw(M6 x 10)	YBA5002
27	Holder(CN751)	CND3898			
28	Holder(CN752)	CND3898	55	Screw	BBZ30P110FTC
29	Holder(CN753)	CND3898	56	Spacer	CNN1954

The Holder Unit(CXC8183) cannot be used again when removing once.

Please exchange it for new parts when you remove the Holder Unit from the product.

Reattachment of the Holder Unit having once peeled off may possibly leak the light from an aperture generated by the weak adhesion of two-sided tape.

9.3 EXTERIOR(2)

A

2

3

4


B

C

D

E

F



EXTERIOR(2) SECTION PARTS LIST


<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
1	Power Supply Unit	CWR1084	
2	Screw	AMZ30P040FTC	A
3	Screw	BBZ30P060FSN	
4	Screw	BSZ30P060FTB	
5	Screw(3 x 8)	CBA2011	
6	Terminal(CN108)	CKE1063	
7	Screw(M12 x 14)	CBA2058	
8	Screw(M4 x 14)	CBA2060	
9	Plug(CN131)	CKS1041	
10	Panel	CNB3375	
11	Buss Bar	CND3820	B
12	Holder(CN271)	CND3898	
13	Holder(CN272)	CND3898	
14	Holder(CN273)	CND3898	
15	Holder(CN274)	CND3898	
16	Holder	CND3923	
17	Buss Bar	CND3926	
18	Buss Bar	CND3927	
19	Sub Heat Sink	CNR1900	
20	Sub Heat Sink	CNR1917	C
21	Screw	PPZ20P060FTB	
22	Screw	PPZ30P100FTB	
23	Fuse Holder(CN101)	YKR5001	
24	Fuse Holder(CN102)	YKR5001	
25	Fuse Holder(CN103)	YKR5001	
26	Fuse Holder(CN104)	YKR5001.	
27	Fuse Holder(CN105)	YKR5001	
28	Fuse Holder(CN106)	YKR5001	
29	Spring	CBL1776	
△ 30	Fuse(40 A) (FU101, 102, 103)	CEK1332	D
△ 31	Fuse(40 A) (FU104, 105, 106)	CEK1332	

E

F

● Screws List

A

Mark A on PCB AMF30P040FTC (3 x 4 Washer Faced Screw)	Mark B on PCB BBZ30P100FTB(3 x 10)	Mark C on PCB CBA2012(3 x 12)
		
Mark D on PCB BBZ30P060FTC(3 x 6)	Mark E on PCB BBZ30P110FTC(3 x 11)	Mark F on PCB PMH40P060FTC (4 x 6 with Spring Washer)
		
Case and Heat Sink BBZ30P060FTC(3 x 6)	Case, Panel and Holder BSZ30P060FTC(3 x 6)	Holder and Panel BBZ30P060FTB(3 x 6)
		
FET CBA2011(3 x 8 Tapping Screw)	Thermistor, Transistor CBA2011(3 x 8 Tapping Screw)	Badge CBA2115(M2.6 x 6)
		
Terminal Cover YBA5002(M6 x 10 Flat-head Screw)		
		

■ 5

■ 6

■ 7

■ 8

■ A

■ B

■ C

■ D


■ E

■ F


10. SCHEMATIC DIAGRAM

10.1 AMP UNIT(GUIDE PAGE)

A Note: When ordering service parts, be sure to refer to " EXPLODED VIEWS AND PARTS LIST" or "ELECTRICAL PARTS LIST".



Large size SCH diagram



Guide page

Detailed page


A-a

B

C

4


□



B POWER SUPPLY UNIT

A

A-b



A

B


C


D

5

F

AMP UNIT





Decimal points for resistor and capacitor fixed values are expressed as :
 $2.2 - 2R2$
 $0.022 - R022$

CN131

7

A-b

33

8

5

6

7

A


B

C


D

E

F



A-a



B POWER SUPPLY UNIT

A-b


A-a A-b

A-a

10.2 POWER SUPPLY UNIT(GUIDE PAGE)

B-a

A AMP UNIT



B

B-b

A


B

C

D

E


F




PBS-D2000SPI /XU/UC

A

B POWER SUPPLY UNIT

**B-b**

**B-b**

A

B-b

B

G


D


E

F

B-b

AMP UNIT





B-b

B-D


PRS-D2000SPL/XU/UC

10.3 REMOTE CONTROL UNIT

A

B

C REMOTE CONTROL UNIT



■ 5

■ 6

■ 7

■ 8

■ A

■ B

■ C

■ D

■ E

■ F

11. PCB CONNECTION DIAGRAM

11.1 AMP UNIT


A

NOTE FOR PCB DIAGRAMS

1. The parts mounted on this PCB include all necessary parts for several destination.

For further information for respective destinations, be sure to check with the schematic diagram.

2. Viewpoint of PCB diagrams



B


C

D

E

F

A AMP UNIT



A

44

PRS-D2000SPL/XU/UC


1

2

3

4

SIDE A



A

A AMP UNIT

⚠ FU 601 (B,200,186) Fuse 3 A CEK1286


6

Q

1

四

8



5


6

7

8

A

SIDE B



PRS-D2000SPL/XU/UC

A

47

11.2 POWER SUPPLY UNIT

B POWER SUPPLY UNIT

A

B


C


D

E

F

B





■ 10 150 160 170 180 190 200 210 220 230 240 250 260 270 280 290 300 310 ■

1

2

3

4

B POWER SUPPLY UNIT

A


B

C

D

E

F



310 300 290 280 270 260 250 240 230 220 210 200 190 180 170 160 150

PRS-D2000SPL/XU/UC

B


50

1

2

3

4



11.3 REMOTE CONTROL UNIT

A


B

C REMOTE CONTROL UNIT

SIDE A

C REMOTE CONTROL UNIT

SIDE B



E

F

C

12. ELECTRICAL PARTS LIST

NOTE:

- Parts whose parts numbers are omitted are subject to being not supplied.
- The part numbers shown below indicate chip components.

Chip Resistor

RS1/○S○○○J, RS1/○○S○○○J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Meaning of the figures and others in the parentheses in the parts list.

Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.

IC 301 (A, 91, 111) IC NJM2068V

<u>Circuit Symbol and No.</u>	<u>Part No.</u>	<u>Circuit Symbol and No.</u>	<u>Part No.</u>
Unit Number: CWH1347		Q 866 (A,79,35) FET	2SK3777-01R
Unit Name : Amp Unit		Q 867 (A,96,35) FET	2SK3777-01R
Unit Number: CWR1084		Q 868 (A,114,35) FET	2SK3777-01R
Unit Name : Power Supply Unit		Q 869 (A,61,199) FET	2SK3777-01R
Unit Number: CWM9848		Q 870 (A,79,199) FET	2SK3777-01R
Unit Name : Remote Control Unit		Q 871 (A,96,199) FET	2SK3777-01R
		Q 872 (A,114,199) FET	2SK3777-01R
		Q 901 (B,143,90) Transistor	2SA1579
		Q 902 (B,141,102) Transistor	2SC4102
		Q 903 (B,136,102) Transistor	2SC4102
		Q 904 (B,135,107) Transistor	2SA1579
		Q 905 (B,136,111) Transistor	2SA1579
		Q 911 (B,93,157) Transistor	2SC4102
		Q 912 (B,105,147) Chip Transistor	2SA1576A
		Q 921 (B,171,88) Transistor	2SC4081
		Q 922 (B,166,88) Transistor	2SC4081

A

Unit Number: CWH1347
Unit Name : Amp Unit

MISCELLANEOUS

IC 501	(B,167,144) IC	NJM2068MD	Q 923	(B,162,88) Chip Transistor	2SA1576A
IC 502	(B,166,128) IC	NJM2068MD	Q 931	(B,127,140) Transistor	2SA1579
IC 521	(B,166,104) IC	NJM4558MD	Q 932	(B,130,152) Transistor	2SC4081
IC 531	(B,178,84) IC	NJM4558MD	Q 933	(B,127,134) Transistor	DTC114WUA
IC 541	(B,170,170) IC	NJM4558MD	Q 941	(B,180,167) Transistor	2SC4081
			Q 942	(B,179,172) Chip Digital Transistor	DTA124EUA
IC 551	(B,161,162) IC	NJM4558MD	D 561	(B,189,144) Diode	UDZS16(B)
IC 561	(B,179,145) IC	MAX309ESE	D 562	(B,186,153) Diode	UDZS16(B)
IC 601	(B,182,200) IC	NJM2068MD	D 581	(A,187,136) Diode	ERA15-02VH
IC 611	(B,188,212) IC	NJM4558MD	D 582	(A,177,124) Diode	ERA15-02VH
IC 721	(A,174,199) IC	TA78L005AP	D 681	(A,188,190) Diode	ERA15-02VH
			D 682	(A,184,190) Diode	ERA15-02VH
IC 811	(B,151,111) IC	NJM4558MD	D 701	(B,158,179) Diode	UDZS16(B)
IC 831	(B,137,122) COMPARATOR IC	NJM311M	D 711	(B,145,188) Diode	UDZS16(B)
IC 841	(B,149,125) COMPARATOR IC	NJM311M	D 731	(B,137,188) Diode	UDZS16(B)
IC 851	(B,141,141) IC	TC74AC14F	D 801	(B,171,119) Diode	MA111
IC 861	(B,134,159) IC	TND505MD	D 802	(B,171,113) Diode	MA111
			D 851	(B,148,135) Diode	MA111
Q 701	(A,153,200) Transistor	2SD2395	D 852	(B,143,133) Diode	MA111
Q 711	(A,141,200) Transistor	2SB1566	D 853	(B,151,140) Diode	MA111
Q 731	(A,129,200) POWER TR	2SC5511	D 854	(B,151,156) Diode	UDZS36(B)
Q 851	(B,143,151) Transistor	IMT4	D 855	(B,144,158) Diode	UDZS36(B)
Q 861	(B,154,97) Transistor	2SC5565	D 861	(A,147,169) Diode	AL01
			D 862	(B,64,46) Diode	RF101L2S
Q 862	(B,100,166) Transistor	2SC5565	D 863	(B,81,46) Diode	RF101L2S
Q 863	(B,154,89) Transistor	2SA2012			
Q 864	(B,89,166) Transistor	2SA2012			
Q 865	(A,61,35) FET	2SK3777-01R			

	<u>Circuit Symbol and No.</u>	<u>Part No.</u>	<u>Circuit Symbol and No.</u>	<u>Part No.</u>
A	D 864 (B,109,46) Diode	RF101L2S	R 544 (B,169,161)	RS1/16S182J
	D 865 (B,126,46) Diode	RF101L2S	R 545 (B,173,154)	RS1/16S101J
	D 866 (B,66,190) Diode	RF101L2S	R 546 (B,190,162)	RS1/16S182J
	D 867 (B,80,190) Diode	RF101L2S	R 551 (B,164,171)	RS1/16S472J
	D 868 (B,95,190) Diode	RF101L2S	R 552 (B,162,171)	RS1/16S472J
	D 869 (B,110,190) Diode	RF101L2S	R 553 (B,186,179)	RS1/16S471J
	D 870 (A,151,169) Diode	AL01	R 554 (B,156,169)	RS1/16S472J
	D 901 (B,144,103) Diode	MA111	R 555 (B,162,155)	RS1/16S472J
	D 902 (B,129,125) Diode	UDZS36(B)	R 561 (B,187,148)	RS1/16S472J
	D 903 (B,146,89) Diode	UDZS36(B)	R 562 (B,195,145)	RS1/16S102J
B	D 904 (B,140,91) Diode	UDZS36(B)	R 563 (B,191,156)	RS1/16S102J
	D 905 (B,146,95) Diode	UDZS27(B)	R 564 (B,193,145)	RS1/16S473J
	D 911 (B,112,144) Diode	MA111	R 565 (B,187,144)	RS1/16S473J
	D 912 (B,98,156) Diode	UDZS36(B)	R 566 (B,189,152)	RS1/16S473J
	D 913 (B,98,150) Diode	UDZS16(B)	R 567 (B,181,154)	RS1/16S104J
	D 921 (B,159,85) Diode	MA111	R 568 (B,179,154)	RS1/16S122J
	D 923 (B,169,77) Diode	MA111	R 569 (B,177,154)	RS1/16S471J
	D 931 (B,131,141) Diode	UDZS36(B)	R 570 (B,175,154)	RS1/16S101J
	D 933 (B,121,135) Diode	MA111	R 601 (B,184,184)	RS1/16S471J
	ZNR581 (B,202,120) Surge Protector	CSA30-201N	R 602 (B,186,190)	RS1/16S0R0J
C	ZNR582 (B,205,128) Surge Protector	CSA30-201N	R 603 (B,181,193)	RS1/16S223J
	ZNR681 (B,203,197) Surge Protector	CSA30-201N	R 604 (B,177,197)	10 kΩ CCN1152
	ZNR682 (B,203,182) Surge Protector	CSA30-201N	R 605 (B,171,188)	10 kΩ CCN1152
	L 881 (A,83,117) Choke Coil 75 µH	CTH1366	R 606 (B,180,208)	10 kΩ CCN1152
	TH881 (A,106,140) Thermistor	CCX1064	R 607 (B,177,202)	10 kΩ CCN1152
	S 501 (A,200,210) Switch(MODE SELECT)	CSH1029	R 608 (B,184,208)	RS1/16S182J
	S 531 (A,200,85) Switch(SUBSONIC SELECT)	CSH1021	R 611 (B,192,162)	RS1/16S101J
	VR521 (A,196,100) Variable Resistor 20 kΩ(E)	CCS1266	R 612 (B,199,138)	RS1/16S101J
	VR541 (A,196,168) Volume 50 kΩ(C)	CCS1263	R 613 (B,192,205)	RS1/16S122J
	VR611 (A,196,139) Variable Resistor 10 kΩ(A)	CCS1265	R 614 (B,189,204)	RS1/16S222J
D	VR801 (A,166,117) Semi-fixed 100 kΩ(OB)	CCP1506	R 615 (B,184,216)	RS1/16S472J
	△FU601 (B,200,186) Fuse 3 A	CEK1286	R 616 (B,184,220)	RS1/16S472J
			R 701 (A,151,181)	RS1/2PMF100J
			R 702 (A,154,195)	RD1/4PU222J
			R 711 (A,130,175)	RS1/2PMF220J
	RESISTORS			
	R 501 (B,183,128)	RS1/16S471J		
	R 502 (B,191,120)	RS1/16S471J	R 712 (A,145,195)	RD1/4PU222J
	R 503 (B,185,135)	RS1/16S0R0J	R 731 (A,135,181)	RS2PMF151J
	R 504 (B,183,123)	RS1/16S0R0J	R 732 (A,130,194)	RS1PMF333J
E	R 505 (B,178,138)	RS1/16S223J	R 733 (A,147,175)	RS2PMF151J
	R 506 (B,177,131)	RS1/16S223J	R 801 (B,173,122)	RS1/16S223J
	R 507 (B,162,146)	10 kΩ CCN1152	R 802 (B,167,112)	RS1/16S223J
	R 508 (B,172,128)	10 kΩ CCN1152	R 803 (B,169,120)	RS1/16S203J
	R 509 (B,163,151)	10 kΩ CCN1152	R 804 (B,169,113)	RS1/16S153J
	R 510 (B,162,136)	10 kΩ CCN1152	R 811 (B,164,117)	RS1/16S222J
	R 511 (B,166,151)	10 kΩ CCN1152	R 812 (B,154,118)	RS1/16S105J
	R 512 (B,167,136)	10 kΩ CCN1152	R 813 (B,149,118)	RS1/16S102J
	R 513 (B,172,141)	10 kΩ CCN1152	R 814 (A,124,150)	RD1/4PU222J
	R 514 (B,173,136)	10 kΩ CCN1152	R 815 (A,124,153)	RD1/4PU102J
F	R 515 (B,169,155)	RS1/16S222J	R 816 (A,113,150)	RS1/2PMF223J
	R 516 (B,171,155)	RS1/16S222J	R 817 (A,112,154)	RS1PMF333J
	R 521 (B,183,98)	RS1/16S222J	R 831 (B,137,130)	RS1/16S562J
	R 522 (B,181,110)	RS1/16S222J	R 832 (B,143,122)	RS1/16S223J
	R 523 (B,176,108)	RS1/16S222J	R 833 (B,143,126)	RS1/16S273J
	R 531 (B,189,84)	RS1/16S333J	R 834 (B,143,118)	RS1/16S223J
	R 532 (B,189,78)	RS1/16S393J	R 835 (A,141,114)	RD1/4PU332J
	R 533 (B,195,88)	RS1/16S153J	R 841 (B,145,118)	RS1/16S104J
	R 535 (B,189,89)	RS1/16S104J	R 851 (B,141,133)	RS1/16S182J
	R 541 (B,184,179)	RS1/16S472J	R 852 (B,150,135)	RS1/16S562J
G	R 542 (B,176,172)	RS1/16S331J	R 853 (B,149,145)	RS1/16S102J
			R 854 (B,148,141)	RS1/16S182J

Circuit Symbol and No.Part No.

R 855	(B,139,150)	RS1/16S332J
R 856	(B,137,150)	RS1/16S332J
R 857	(B,148,157)	RS1/16S113J
R 858	(B,146,158)	RS1/16S113J
R 861	(A,140,171)	RD1/4PU0R0J
R 862	(B,158,93)	RS1/16S104J
R 863	(B,96,167)	RS1/16S104J
R 864	(A,68,46)	RS1/2PMF470J
R 865	(A,84,46)	RS1/2PMF470J
R 866	(A,105,46)	RS1/2PMF470J
R 867	(A,122,46)	RS1/2PMF470J
R 868	(A,66,187)	RS1/2PMF470J
R 869	(A,80,187)	RS1/2PMF470J
R 870	(A,95,187)	RS1/2PMF470J
R 871	(A,110,187)	RS1/2PMF470J
R 872	(A,66,192)	RS1/2PMF150J
R 873	(A,80,192)	RS1/2PMF150J
R 874	(A,95,192)	RS1/2PMF150J
R 875	(A,110,192)	RS1/2PMF150J
R 881	(A,92,47) 0.01 Ω	CCN1158
R 882	(A,100,176) 0.01 Ω	CCN1158
R 883	(A,99,47) 0.01 Ω	CCN1158
R 884	(A,107,176) 0.01 Ω	CCN1158
R 885	(A,52,48)	RS2PMF100J
R 886	(A,41,194)	RS2PMF100J
R 887	(A,103,76)	RS2PMF100J
R 888	(A,110,76)	RS2PMF100J
R 901	(B,137,90)	RS1/16S152J
R 902	(B,146,99)	RS1/16S222J
R 903	(B,148,103)	RS1/16S473J
R 904	(B,140,97)	RS1/16S104J
R 905	(B,142,109)	RS1/16S473J
R 906	(B,132,104)	RS1/16S472J
R 907	(B,138,97)	RS1/16S473J
R 908	(B,132,109)	RS1/16S472J
R 909	(B,126,127)	RS1/16S104J
R 911	(B,94,147)	RS1/16S102J
R 912	(B,96,157)	RS1/16S104J
R 913	(B,103,152)	RS1/16S472J
R 914	(B,109,145)	RS1/16S222J
R 915	(B,117,146)	RS1/16S103J
R 921	(B,169,82)	RS1/16S472J
R 922	(B,159,80)	RS1/16S472J
R 923	(B,164,80)	RS1/16S822J
R 924	(B,167,82)	RS1/16S472J
R 928	(B,158,61)	RS1/16S473J
R 931	(B,134,143)	RS1/16S822J
R 932	(B,131,136)	RS1/16S332J
R 933	(B,131,146)	RS1/16S472J
R 935	(B,133,152)	RS1/16S103J
R 936	(B,123,132)	RS1/16S103J
R 937	(B,124,166)	RS1/16S103J
R 941	(B,183,166)	RS1/16S472J
R 942	(B,163,175)	RS1/16S102J
R 999	(A,115,139)	RD1/4PU103J

Part No.Circuit Symbol and No.

C 502	(B,189,122)	CCSRCH471J50
C 503	(A,182,133)	CEHAT100M50
C 504	(A,175,133)	CEHAT100M50
C 505	(B,188,129)	CKSRYB223K50
C 506	(B,189,118)	CKSRYB223K50
C 507	(B,162,141)	CKSRYB103K50
C 508	(B,163,121)	CKSRYB103K50
C 509	(B,161,151)	CCSRCH271J50
C 510	(B,164,136)	CCSRCH271J50
C 511	(B,172,149)	CKSRYB103K50
C 512	(B,172,132)	CKSRYB103K50
C 513	(B,168,151)	CCSRCH271J50
C 514	(B,169,136)	CCSRCH271J50
C 521	(A,176,109)	CFTNA154J50
C 522	(A,176,103)	CFTNA154J50
C 523	(B,171,107)	CKSRYB103K50
C 524	(A,176,91)	CFTNA154J50
C 525	(A,176,97)	CFTNA474J50
C 526	(B,165,96)	CKSRYB103K50
C 531	(A,190,81)	CFTNA224J50
C 532	(A,190,75)	CFTNA224J50
C 533	(B,173,84)	CKSRYB103K50
C 534	(A,189,86)	CFTNA224J50
C 535	(A,189,92)	CFTNA224J50
C 536	(B,182,92)	CKSRYB103K50
C 541	(A,186,171)	CEHAT4R7M50
C 542	(A,181,180)	CFTNA224J50
C 543	(B,177,178)	CKSRYB103K50
C 544	(B,166,171)	CKSRYB103K50
C 545	(A,168,161)	CFTNA273J50
C 551	(B,160,171)	CKSRYB272K50
C 552	(B,166,162)	CKSRYB103K50
C 553	(B,164,155)	CKSRYB272K50
C 554	(A,175,180)	CEHAT100M50
C 555	(B,159,155)	CKSRYB103K50
C 561	(B,194,149)	CKSQYB102K50
C 562	(B,189,156)	CKSQYB102K50
C 563	(B,191,145)	CKSRYB473K50
C 564	(B,172,145)	CKSRYB103K50
C 565	(B,191,152)	CKSRYB473K50
C 566	(B,183,153)	CKSRYB103K50
C 581	(B,199,121)	CKSQYB102K50
C 582	(B,202,127)	CKSQYB102K50
C 601	(B,178,187)	CCSRCH471J50
C 602	(A,175,188)	CEHAT100M50
C 603	(B,180,188)	CKSRYB104K50
C 604	(B,178,192)	CKSRYB103K50
C 605	(B,172,188)	CCSRCH271J50
C 606	(B,187,200)	CKSRYB103K50
C 607	(B,182,208)	CCSRCH271J50
C 611	(B,194,206)	CKSRYB272K50
C 612	(B,182,212)	CKSRYB103K50
C 613	(B,193,214)	CKSRYB103K50
C 614	(B,186,220)	CKSRYB272K50
C 681	(B,200,196)	CKSQYB102K50
C 682	(B,200,182)	CKSQYB102K50
C 701	(A,161,188)	CEHAT100M50
C 702	(A,161,180)	CEHAT470M25
C 703	(B,163,180)	CKSRYB103K50
C 704	(A,162,199)	CEHAT470M25

CAPACITORS

C 501	(B,180,138)	CCSRCH471J50
-------	-------------	--------------

Part No.Circuit Symbol and No.

C 502	(B,189,122)	CCSRCH471J50
C 503	(A,182,133)	CEHAT100M50
C 504	(A,175,133)	CEHAT100M50
C 505	(B,188,129)	CKSRYB223K50
C 506	(B,189,118)	CKSRYB223K50
C 507	(B,162,141)	CKSRYB103K50
C 508	(B,163,121)	CKSRYB103K50
C 509	(B,161,151)	CCSRCH271J50
C 510	(B,164,136)	CCSRCH271J50
C 511	(B,172,149)	CKSRYB103K50
C 512	(B,172,132)	CKSRYB103K50
C 513	(B,168,151)	CCSRCH271J50
C 514	(B,169,136)	CCSRCH271J50
C 521	(A,176,109)	CFTNA154J50
C 522	(A,176,103)	CFTNA154J50
C 523	(B,171,107)	CKSRYB103K50
C 524	(A,176,91)	CFTNA154J50
C 525	(A,176,97)	CFTNA474J50
C 526	(B,165,96)	CKSRYB103K50
C 531	(A,190,81)	CFTNA224J50
C 532	(A,190,75)	CFTNA224J50
C 533	(B,173,84)	CKSRYB103K50
C 534	(A,189,86)	CFTNA224J50
C 535	(A,189,92)	CFTNA224J50
C 536	(B,182,92)	CKSRYB103K50
C 541	(A,186,171)	CEHAT4R7M50
C 542	(A,181,180)	CFTNA224J50
C 543	(B,177,178)	CKSRYB103K50
C 544	(B,166,171)	CKSRYB103K50
C 545	(A,168,161)	CFTNA273J50
C 551	(B,160,171)	CKSRYB272K50
C 552	(B,166,162)	CKSRYB103K50
C 553	(B,164,155)	CKSRYB272K50
C 554	(A,175,180)	CEHAT100M50
C 555	(B,159,155)	CKSRYB103K50
C 561	(B,194,149)	CKSQYB102K50
C 562	(B,189,156)	CKSQYB102K50
C 563	(B,191,145)	CKSRYB473K50
C 564	(B,172,145)	CKSRYB103K50
C 565	(B,191,152)	CKSRYB473K50
C 566	(B,183,153)	CKSRYB103K50
C 581	(B,199,121)	CKSQYB102K50
C 582	(B,202,127)	CKSQYB102K50
C 601	(B,178,187)	CCSRCH471J50
C 602	(A,175,188)	CEHAT100M50
C 603	(B,180,188)	CKSRYB104K50
C 604	(B,178,192)	CKSRYB103K50
C 605	(B,172,188)	CCSRCH271J50
C 606	(B,187,200)	CKSRYB103K50
C 607	(B,182,208)	CCSRCH271J50
C 611	(B,194,206)	CKSRYB272K50
C 612	(B,182,212)	CKSRYB103K50
C 613	(B,193,214)	CKSRYB103K50
C 614	(B,186,220)	CKSRYB272K50
C 681	(B,200,196)	CKSQYB102K50
C 682	(B,200,182)	CKSQYB102K50
C 701	(A,161,188)	CEHAT100M50
C 702	(A,161,180)	CEHAT470M25
C 703	(B,163,180)	CKSRYB103K50
C 704	(A,162,199)	CEHAT470M25

1 Circuit Symbol and No.	2 Part No.	3 Circuit Symbol and No.	4 Part No.
C 705 (B,159,198)	CKSRYB103K50	C 932 (B,134,148)	CKSRYB473K50
C 711 (A,147,188)	CEHAT100M50	C 933 (B,117,170)	CKSRYB102K50
C 712 (A,141,188)	CEHAT470M25	C 941 (B,177,168)	CKSRYB474K16
C 713 (B,143,187)	CKSRYB103K50	C 942 (B,191,51) 0.22 µF	ACG1125
C 714 (A,154,188)	CEHAT470M25	C 943 (B,187,51) 0.22 µF	ACG1125
C 715 (B,152,189)	CKSRYB103K50	C 944 (B,183,51) 0.22 µF	ACG1125
C 721 (A,168,199)	CFTNA104J50	C 945 (B,179,51) 0.22 µF	ACG1125
C 722 (B,170,194)	CKSRYB104K50		
C 723 (A,168,188)	CEHAT100M50		
C 731 (B,131,188) 0.22 µF	ACG1125		
C 732 (A,134,188)	CEHAT470M25		
C 733 (A,126,188)	CEHAT470M25		
C 734 (B,125,188)	CKSRYB473K50		
C 735 (A,120,185)	CQMA103K2E		
C 801 (A,168,180)	CEHAT220M50	IC 131 (A,158,117) IC	PA2027A
C 811 (B,152,118)	CKSRYB222K50	IC 201 (B,187,74) IC	UPC494GS
C 812 (B,155,111)	CKSRYB103K50	IC 301 (B,185,112) IC	NJM2903M
C 813 (B,147,111)	CKSRYB103K50	IC 401 (B,184,138) IC	TC74HC279AF
C 814 (B,114,153)	CKSRYB471K50	IC 402 (A,168,140) IC	TA78L005AP
C 815 (B,155,123)	CKSRYB103K50	Q 101 (B,142,110) Chip Transistor	2SA1576A
C 831 (B,139,129)	CKSRYB471K50	Q 102 (B,149,104) Transistor	2SC4081
C 832 (B,134,130)	CKSRYB103K50	Q 111 (B,174,144) Transistor	DTC114WUA
C 833 (B,133,123)	CKSRYB103K50	Q 112 (B,177,144) Transistor	DTA114TUA
C 834 (B,147,118)	CKSRYB471K50	Q 132 (B,166,94) Chip Transistor	DTC114TUA
C 842 (B,145,126)	CKSRYB103K50	Q 135 (B,166,89) Transistor	2SC4081
C 843 (B,155,132)	CKSRYB103K50	Q 136 (A,177,102) Transistor	2SB1243
C 851 (B,146,133)	CKSRYB221K50	Q 161 (A,52,35) FET	2SK2907-01R
C 852 (B,149,149)	CKSRYB104K50	Q 162 (A,69,35) FET	2SK2907-01R
C 853 (B,148,149)	CKSRYB221K50	Q 163 (A,87,35) FET	2SK2907-01R
C 861 (B,136,152)	CKSRYB104K50	Q 164 (A,104,35) FET	2SK2907-01R
C 862 (B,141,168)	CKSRYB104K50	Q 165 (A,146,35) FET	2SK2907-01R
C 863 (B,131,168)	CKSRYB104K50	Q 166 (A,164,35) FET	2SK2907-01R
C 864 (A,140,166)	CEHAT220M50	Q 167 (A,181,35) FET	2SK2907-01R
C 865 (A,130,166)	CEHAT331M25	Q 168 (A,199,35) FET	2SK2907-01R
C 866 (B,151,93)	CKSRYB474K16	Q 169 (A,157,83) Transistor	2SD1864
C 867 (B,117,48)	CKSQYB472K50	Q 170 (A,157,78) Transistor	2SB1243
C 868 (B,94,167)	CKSQYB472K50	Q 171 (A,170,78) Transistor	2SB1243
C 869 (B,96,163)	CKSRYB474K16	Q 172 (A,170,83) Transistor	2SD1864
C 883 (A,76,70) 2 200 µF/160 V	CCH1741	Q 201 (A,52,199) FET	2SK2907-01R
C 884 (A,76,165) 2 200 µF/160 V	CCH1741	Q 202 (A,69,199) FET	2SK2907-01R
C 885 (A,48,43)	CQMA102K2E	Q 203 (A,87,199) FET	2SK2907-01R
C 886 (A,47,188)	CQMA102K2E	Q 204 (A,104,199) FET	2SK2907-01R
C 887 (A,59,48) 1 µF	CCE1035	Q 205 (A,146,199) FET	2SK2907-01R
C 890 (A,54,186) 1 µF	CCE1035	Q 206 (A,164,199) FET	2SK2907-01R
C 891 (A,127,97) 10 µF	CCE1038	Q 207 (A,181,199) FET	2SK2907-01R
C 892 (A,127,68) 10 µF	CCE1038	Q 208 (A,199,199) FET	2SK2907-01R
C 893 (B,189,71)	CKSRYB102K50	Q 209 (A,158,152) Transistor	2SD1864
C 894 (B,187,71)	CKSRYB103K50	Q 210 (A,158,157) Transistor	2SB1243
C 895 (B,194,51) 2 200 pF	CCG1248	Q 211 (A,170,157) Transistor	2SB1243
C 896 (B,205,74)	CKSQYB102K50	Q 212 (A,170,152) Transistor	2SD1864
C 898 (A,36,70) 2 200 µF/160 V	CCH1741	Q 301 (B,186,98) Chip Transistor	DTC114TUA
C 899 (A,36,165) 2 200 µF/160 V	CCH1741	Q 401 (B,179,129) Transistor	DTC114WUA
C 901 (B,135,90)	CKSQYB224K50	Q 402 (B,184,129) Transistor	DTC114WUA
C 902 (B,146,103)	CKSRYB103K50	Q 403 (B,190,129) Transistor	DTC114WUA
C 903 (B,142,97)	CKSQYB103K50	Q 404 (B,195,137) Chip Transistor	DTC114EUA
C 911 (B,92,152)	CKSQYB224K50	Q 405 (B,195,130) Chip Transistor	DTC114EUA
C 912 (B,101,152)	CKSRYB104K50	D 101 (B,147,129) Diode	1SR154-400
C 913 (B,115,146)	CKSRYB104K50	D 102 (B,143,129) Diode	1SR154-400
C 914 (B,94,152)	CKSQYB103K50	D 103 (A,47,94) Diode	RM4Z-LFJ4
C 921 (A,162,80)	CFHANP221M10	D 104 (A,47,139) Diode	RM4Z-LFJ4

B

Unit Number : CWR1084
Unit Name : Power Supply Unit

MISCELLANEOUS

<u>Circuit Symbol and No.</u>		
D 107	(A,47,102)	Diode
D 108	(A,47,131)	Diode
D 109	(B,146,111)	Diode
D 110	(B,162,147)	Diode

D 131	(B,170,90)	Diode	MA111	R 140	(A,177,93)	RD1/4PU392J
D 132	(B,262,197)	LED	VUB1112H-4B63B	R 141	(A,177,97)	RD1/4PU101J
D 133	(B,170,96)	Diode	MA111	R 142	(A,168,102)	RD1/4PU472J
D 201	(B,131,113)	Diode	DAN202U	R 143	(B,164,122)	RS1/16S223J
D 202	(B,131,120)	Diode	DAN202U	R 144	(A,177,106)	RD1/4PU221J
D 203	(B,139,120)	Diode	DAN202U	R 145	(A,168,106)	RD1/4PU152J
D 241	(A,252,34)	Diode	FML22S	R 146	(B,166,127)	RS1/16S223J
D 242	(A,216,199)	Diode	FML22S	R 147	(B,166,131)	RS1/16S223J
D 243	(A,228,34)	Diode	FML22S	R 148	(A,172,127)	RD1/4PU0R0J
D 244	(A,240,199)	Diode	FML22S	R 149	(A,172,124)	RD1/4PU0R0J
D 245	(A,216,34)	Diode	FML22S	R 161	(A,85,56)	RS1/2PMF220J
D 246	(A,252,199)	Diode	FML22S	R 162	(A,144,63)	RS1/2PMF220J
D 247	(A,240,34)	Diode	FML22S	R 163	(A,45,48) 22 Ω	CCN1162
D 248	(A,228,199)	Diode	FML22S	R 164	(A,59,48) 22 Ω	CCN1162
D 249	(B,266,93)	Diode	1SR154-400	R 165	(A,74,48) 22 Ω	CCN1162
D 250	(B,270,93)	Diode	1SR154-400	R 166	(A,88,48) 22 Ω	CCN1162
D 251	(B,266,140)	Diode	1SR154-400	R 167	(A,141,48) 22 Ω	CCN1162
D 252	(B,270,140)	Diode	1SR154-400	R 168	(A,155,48) 22 Ω	CCN1162
D 253	(B,266,104)	Diode	1SR154-400	R 169	(A,170,48) 22 Ω	CCN1162
D 254	(B,270,104)	Diode	1SR154-400	R 170	(A,184,48) 22 Ω	CCN1162
D 255	(B,266,130)	Diode	1SR154-400	R 171	(B,163,81)	RS1/8S472J
D 256	(B,270,130)	Diode	1SR154-400	R 172	(B,176,81)	RS1/8S472J
D 301	(B,177,120)	Diode	DAN202U	R 173	(A,157,74)	RD1/4PU332J
D 302	(B,190,114)	Diode	MA111	R 174	(A,170,74)	RD1/4PU332J
D 401	(B,262,163)	LED	FY1112H	R 201	(A,85,177)	RS1/2PMF220J
D 402	(B,262,180)	LED	FR1112H	R 202	(A,144,172)	RS1/2PMF220J
D 403	(B,166,136)	Diode	MA111	R 203	(A,45,185) 22 Ω	CCN1162
T 161	(A,111,82)	Transformer	CTT1138	R 204	(A,59,185) 22 Ω	CCN1162
T 201	(A,111,152)	Transformer	CTT1138	R 205	(A,74,185) 22 Ω	CCN1162
TH201	(A,136,107)	Thermistor	CCX1064	R 206	(A,88,185) 22 Ω	CCN1162
TH202	(A,118,36)	Thermistor	CCX1013	R 207	(A,141,185) 22 Ω	CCN1162
TH203	(A,118,198)	Thermistor	CCX1013	R 208	(A,155,185) 22 Ω	CCN1162
TH204	(A,137,126)	Thermistor	CCX1064	R 209	(A,170,185) 22 Ω	CCN1162
S 201	(A,10,83)	Slide Switch(BFC)	CSH1072	R 210	(A,184,185) 22 Ω	CCN1162
▲FU101	(A,13,60)	Fuse 40 A	CEK1332	R 211	(B,151,155)	RS1/8S472J
▲FU102	(A,13,45)	Fuse 40 A	CEK1332	R 212	(B,164,155)	RS1/8S472J
▲FU103	(A,13,30)	Fuse 40 A	CEK1332	R 213	(A,158,161)	RD1/4PU332J
▲FU104	(A,13,174)	Fuse 40 A	CEK1332	R 214	(A,170,161)	RD1/4PU332J
▲FU105	(A,13,189)	Fuse 40 A	CEK1332	R 215	(B,134,113)	RS1/16S272J
▲FU106	(A,13,204)	Fuse 40 A	CEK1332	R 216	(B,128,113)	RS1/16S272J

RESISTORS

<u>Circuit Symbol and No.</u>			<u>Part No.</u>	<u>Circuit Symbol and No.</u>			<u>Part No.</u>
R 101	(B,152,113)		RS1/16S472J	R 224	(B,138,115)	RS1/16S272J	
R 102	(B,150,119)		RS1/16S472J	R 225	(B,190,84)	RS1/16S105J	
R 103	(B,148,119)		RS1/16S472J	R 226	(B,188,84)	RS1/16S153J	
R 104	(B,150,123)		RS1/16S103J	R 228	(B,185,66)	RS1/16S472J	
R 105	(B,139,110)		RS1/16S472J	R 241	(A,276,59)	RS2PMF332J	
R 106	(B,146,104)		RS1/16S222J	R 242	(A,283,59)	RS2PMF332J	
R 107	(B,148,109)		RS1/16S103J	R 243	(A,290,59)	RS2PMF332J	
R 108	(B,150,109)		RS1/16S103J	R 244	(A,290,174)	RS2PMF332J	
R 109	(B,148,113)		RS1/16S473J	R 245	(A,283,174)	RS2PMF332J	
R 110	(A,37,124)		RD1/4PU222J	R 246	(A,276,174)	RS2PMF332J	
R 131	(B,177,89)		RS1/16S182J	R 249	(A,148,92)	RS1/2PMF220J	
R 132	(B,179,89)		RS1/16S0R0J	R 250	(A,148,143)	RS1/2PMF220J	
R 133	(B,181,89)		RS1/16S273J	R 301	(B,185,120)	RS1/16S1202F	
R 138	(A,192,148)		RD1/4PU471J	R 302	(B,187,120)	RS1/16S1803F	

	Circuit Symbol and No.	Part No.	Circuit Symbol and No.	Part No.
A	R 303 (B,190,120)	RS1/16S6802F	C 254 (A,148,149)	CQMA102K2E
	R 305 (B,182,103)	RS1/16S273J	C 255 (A,279,80)	CEHAT102M50(P35)
	R 306 (B,191,103)	RS1/16S4702F	C 256 (A,279,153)	CEHAT102M50(P35)
	R 307 (B,189,103)	RS1/16S1803F	C 257 (B,287,119)	CKSRYB104K50
	R 308 (B,189,109)	RS1/16S1202F	C 258 (B,287,123)	CKSRYB104K50
	R 309 (B,187,103)	RS1/16S101J	C 301 (A,197,122)	CEHANP1R0M50
	R 310 (B,185,103)	RS1/16S2201F	C 302 (B,181,111)	CKSRYB103K50
	R 311 (B,183,98)	RS1/16S2201F	C 303 (A,192,99)	CEHAT220M50
	R 401 (B,181,129)	RS1/16S103J	C 304 (A,195,108)	CEHAT470M25
B	R 402 (B,187,129)	RS1/16S103J	C 401 (B,192,140)	CKSRYB104K50
	R 403 (B,192,129)	RS1/16S103J	C 402 (B,171,136)	CKSRYB104K50
	R 404 (B,202,137)	RS1/8S820J	C 403 (B,162,142)	CKSQYB334K50
	R 405 (B,199,137)	RS1/8S820J		
C	R 406 (B,202,130)	RS1/8S820J		
	R 407 (B,199,130)	RS1/8S820J		
CAPACITORS				
C	C 101 (B,152,127)	CKSRYB104K50		
	C 102 (A,158,131)	CEHAT100M50		
	C 103 (B,152,123)	CKSRYB103K50		
	C 108 (B,57,108)	CKSQYB103K50		
	C 109 (B,57,126)	CKSQYB103K50		
	C 110 (B,150,113)	CKSRYB103K50		
	C 113 (B,22,125)	CKSQYB104K50		
	C 115 (B,25,119)	CKSQYB103K50		
	C 117 (B,22,119)	CKSQYB105K25		
D	C 118 (B,168,145)	CKSRYB103K50		
	C 131 (A,187,89)	CEHANP221M10		
	C 133 (B,262,195)	CKSQYB104K50		
	C 134 (A,160,94)	CEHAT471M25		
	C 136 (B,158,105)	CKSRYB103K50		
	C 137 (B,164,127)	CKSRYB103K50		
	C 138 (B,277,112)	CKSRYB102K50		
	C 139 (B,279,112)	CKSRYB102K50		
	C 140 (B,279,119)	CKSRYB102K50		
E	C 141 (B,164,131)	CKSRYB103K50		
	C 142 (A,158,103)	CEHAT220M50		
	C 161 (A,70,69) 4 700 μ F/25 V	CCH1738(P45)		
	C 162 (A,70,104) 4 700 μ F/25 V	CCH1738(P45)		
	C 163 (A,70,87) 4 700 μ F/25 V	CCH1738(P45)		
	C 164 (A,73,56)	CQMA472J50		
	C 165 (A,146,58)	CQMA472J50		
	C 201 (A,70,165) 4 700 μ F/25 V	CCH1738(P45)		
	C 202 (A,70,147) 4 700 μ F/25 V	CCH1738(P45)		
F	C 203 (A,70,130) 4 700 μ F/25 V	CCH1738(P45)		
	C 204 (A,73,177)	CQMA472J50		
	C 205 (A,146,178)	CQMA472J50		
	C 206 (B,194,76)	CKSRYB223K50		
	C 207 (A,200,76)	CEHAT221M25		
	C 209 (B,131,109)	CKSRYB104K50		
	C 211 (B,131,125)	CKSRYB104K50		
	C 212 (B,184,84)	CKSRYB472K50		
	C 213 (B,186,84)	CKSRYB102K50		
G	C 214 (B,140,115)	CKSRYB103K50		
	C 243 (A,214,95) 2 200 μ F/160 V	CCH1741		
	C 244 (A,214,139) 2 200 μ F/160 V	CCH1741		
H	C 247 (A,253,95) 2 200 μ F/160 V	CCH1741		
	C 248 (A,253,139) 2 200 μ F/160 V	CCH1741		
	C 253 (A,148,86)	CQMA102K2E		
MISCELLANEOUS				
C	Q 1351 (B,21,23)	Chip Transistor	DTC114EUA	
	Q 1352 (B,22,6)	Chip Transistor	DTC114EUA	
	D 1351 (B,12,25)	Diode	DAN202U	
	D 1352 (B,16,6)	Diode	DAN202U	
	D 1366 (B,21,11)	Diode	UDZS16(B)	
	D 1367 (B,29,16)	Diode	UDZS16(B)	
	S 1351 (A,6,11)	Switch(BASS BOOST)	CSD1128	
RESISTORS				
D	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
E	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
F	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
G	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
H	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
I	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
J	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
K	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
L	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
M	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
N	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
O	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
P	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
Q	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
R	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS1/16S102J	
RESISTORS				
S	R 1351 (B,15,16)		RS1/16S103J	
	R 1352 (B,18,18)		RS1/16S102J	
	R 1353 (B,31,21)		RS1/16S103J	
	R 1354 (B,31,16)		RS1/16S102J	
	R 1359 (B,16,8)		RS	